



Flame Tracker*

SiC Two Wire Flame Sensor

Reuter-Stokes

Model RS-FS-9006

GE 07482SOCNL44819P01

Operation and Maintenance Manual

FS-9006OM Rev. K

November 2017

www.gemeasurement.com

* A trademark of Baker Hughes, a GE company, LLC
©2017 Baker Hughes, a GE company. All rights reserved.
Technical content subject to change without notice.

NOTICE

All content and material in this Manual (including, without limitation, text, design, graphics, logos, icons, images, code and software, as well as the selection and arrangement thereof) is confidential and proprietary, the exclusive property of and owned by Reuter-Stokes, LLC. and is protected by copyright, trademark and other applicable laws. Any use of content and material in this Manual, including but not limited to the modification, distribution, transmission, performance, broadcast, publication, uploading, licensing, reverse engineering, transfer or sale of, or the creation of derivative works from, any material, information, software, products or services obtained from the content and material in this Manual, or use thereof for purposes competitive to Reuter-Stokes, LLC., is expressly prohibited.

WHILE EVERY ATTEMPT HAS BEEN MADE TO ASSURE THE COMPLETENESS, ACCURACY AND TIMELINESS OF THE CONTENT AND MATERIAL IN THIS MANUAL, IT IS PROVIDED ON AN "AS IS" AND "AS AVAILABLE" BASIS. REUTER-STOKES, LLC. EXPRESSLY DISCLAIMS ALL WARRANTIES OF ANY KIND, WHETHER EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE AND ANY WARRANTIES THAT THE CONTENT AND MATERIAL IN THIS MANUAL IS NONINFRINGEMENT, AS WELL AS WARRANTIES IMPLIED FROM A COURSE OF PERFORMANCE OR COURSE OF DEALING; THE MATERIALS IN THIS MANUAL WILL BE ERROR-FREE; OR THAT THE MATERIALS IN THIS MANUAL WILL BE COMPLETE, ACCURATE OR TIMELY. NO ADVICE OR INFORMATION, OBTAINED BY YOU FROM REUTER-STOKES, LLC. OR THROUGH THE CONTENT AND MATERIAL IN THIS MANUAL SHALL CREATE ANY WARRANTY OF ANY KIND. REUTER-STOKES, LLC. DOES NOT MAKE ANY WARRANTIES OR REPRESENTATIONS REGARDING THE USE OF THE CONTENT AND MATERIAL IN THIS MANUAL IN TERMS OF THEIR COMPLETENESS, CORRECTNESS, ACCURACY, ADEQUACY, USEFULNESS, TIMELINESS, RELIABILITY OR OTHERWISE.

YOU ACKNOWLEDGE AND AGREE THAT YOU ASSUME FULL RESPONSIBILITY FOR YOUR USE OF THE CONTENT AND MATERIAL IN THIS MANUAL. YOU ACKNOWLEDGE AND AGREE THAT YOUR USE OF THE CONTENT AND MATERIAL IN THIS MANUAL IS AT YOUR OWN RISK. YOU ACKNOWLEDGE AND AGREE THAT, TO THE FULLEST EXTENT PERMITTED BY APPLICABLE LAW, REUTER-STOKES, LLC. WILL NOT BE LIABLE FOR ANY DIRECT, INDIRECT, PUNITIVE, EXEMPLARY, INCIDENTAL, SPECIAL, CONSEQUENTIAL OR OTHER DAMAGES ARISING OUT OF OR IN ANY WAY RELATED TO THE CONTENT AND MATERIAL IN THIS MANUAL, WHETHER BASED ON CONTRACT, TORT, STRICT LIABILITY OR OTHERWISE. THIS DISCLAIMER APPLIES, WITHOUT LIMITATION, TO ANY DAMAGES OR INJURY ARISING FROM ANY FAILURE OF PERFORMANCE, ERROR, OMISSION, YOUR LOSS OF PROFITS, DESTRUCTION, AND ANY OTHER TANGIBLE OR INTANGIBLE LOSS.

Copyright © 2017 Baker Hughes, a GE company.

Contains Baker Hughes, a GE company Confidential Information.

Revision History

REV#: G DATE: 10/2006	ECN#: 7233394	WRTR: K. Schmidt
REV#: D DATE: 10/12/2009	ECN#: 7233394	WRTR: L. Lombardo
REV#: E DATE: 06/25/10	ECN#: 40293054	WRTR: R. Martin
REV#: F DATE: 04/24/13	ECN#: 77469075	WRTR: J. Hashmi
REV#: G DATE: 12/18/15	ECN#: 500000157848	WRTR: J. Hashmi
REV#: H DATE: 02/22/16	ECN#: 500000204318	WRTR: J. Hashmi
REV#: J DATE: 08/24/17	ECN#: 500000263564	WRTR: J. Hashmi
REV#: K DATE: 11/03/17	ECN#: 500000272164	WRTR: J. Hashmi

Certification Information

ATTENTION! The RS-FS-9006 **Flame Tracker** sensor complies with the following standards:


ETL



Intertek Control Number 9900287

Class 1, Div. 2, Grp A,B,C,D T3
Class 1, Zone 2 AEx nA IIC T3 Gc

ATEX / IECEx



Ex nA IIC T3 Gc

Temperature Range

$-40^{\circ}\text{C} \leq T_a \leq 150^{\circ}\text{C}; T3$

$-40^{\circ}\text{C} \leq T_a \leq 235^{\circ}\text{C}; T2 ; \text{with cooling coil}$



South Korea KTL
hazardous area mark



Customs Union
hazardous area mark



China hazardous
area mark



Brazil INMETRO
hazardous area mark

India hazardous
area approved.



TD00000
Taiwan hazardous
area mark

These certifications are based on the use of approved interconnecting cables only. Currently available approved interconnecting cables are BHGE Reuter-Stokes RS-E2-0285PXXX and GE 362A1053PXXX. See Section 1.1.2 for details.

WARNING

Do not disconnect connector while circuit is energized (or live), unless area is known to be non-hazardous.

Certifications are based on the use of approved cables only. Currently available approved cables are BHGE Reuter-Stokes RS-E2-0279 and GE AE 07482SOCNL44820.

Do not attempt to disassemble the sensor. Sensors are not repairable. Breaching the seal of the sensor will cause loss of the inert fill gas and render the sensor unusable.

Do not remove the sensor by wrenching on the body. Always use the 1 3/8 inch mounting nut. Wrenching on the body may breach the seal. Breaching the seal of the sensor will cause loss of the inert fill gas and render the sensor unusable.

Do not install a sensor that has a cracked window, damaged threads or one that has been disassembled.

Do not install or remove the flame sensor from the sight tube with the cooling coils attached to the flame sensor. Sensor disassembly and malfunction may occur, possibly resulting in a false Flame On signal.

CAUTION

The operating temperature range of the Flame Sensor is **-40°C to 150°C**. Do not attempt to work on the Flame Sensor until it has reached a safe handling temperature.

TABLE OF CONTENTS

1 INTRODUCTION1

1.1 SPECIFICATIONS.....1

 1.1.1 Flame Tracker™ -RS-FS-9006.....1

 1.1.2 INTERCONNECTING CABLE RS-E2-0279PXXX OR 362A1053PXXX.....2

1.2 REFERENCE.....3

1.3 GENERAL DESCRIPTION.....4

2 SENSOR.....4

3 INSTALLATION5

 3.1 MECHANICAL5

 3.2 ELECTRICAL.....7

 3.3 CONNECTOR PINOUT8

 3.4 SENSOR CHECKOUT8

 3.5 CONTROLLER SETUP8

4 Maintenance9

 4.1 WARNING9

 4.2 CAUTION.....9

5 TROUBLESHOOTING.....9

 5.1 WARNING9

 5.2 CAUTION.....9

1 INTRODUCTION

1.1 SPECIFICATIONS

1.1.1 Flame Tracker™ -RS-FS-9006

Mechanical

Body Mount:	AISI316 Stainless Steel
Housing:	AISI304 Stainless Steel (sealed and Argon filled)
Connector	
Process:	3/4" NPT female
Electrical:	MIL-C-38999 Series III size 15 (5 pin)
Sensor:	Silicon Carbide photodiode
Window:	Sapphire

Operating

Sensitivity:	>5 mA @ 1x10 ¹⁰ photons/in ² /sec. @ 310 nm
Output:	4 - 20 mA dc, Max < 21 mA
Response Time:	<25 milliseconds
Power Requirements:	12 - 30 vdc @ 100 mA
Temperature Range (ambient):	-40°F to 302°F (-40°C to 150°C) 455°F (235°C) with specified air cooling
Relative Humidity	100% Non-Condensing
Process Pressure	400 psig (2.8 Mpa)
Vibration	0.0125 inches DA 10 – 88 Hz 5 G continuous 88 – 1200 Hz

1.1.2 INTERCONNECTING CABLE RS-E2-0279PXXX OR 362A1053PXXX



Mechanical

Wire	18 gauge (1.02 mm), 19 strand nickel plated copper
Insulation	Teflon PTFE
Shield	36 gauge (0.127 mm) nickel plated copper braid
Jacket	Extruded PFA
Armor	Stainless steel braid
Connector	MIL-C-38999 series III, shell size 15, 5 #16 pins (only 3 pins are used)

Operating

Voltage (max)	300 vrms
Temperature (max)	482°F (250°C)

1.2 REFERENCE



1.3 GENERAL DESCRIPTION


On Liquid Dry Low Nox Applications as well as those applications with significant levels of water and steam injection, the ultra-violet light sensed by the Geiger Mueller tube based flame detectors is absorbed by the fog of fuel, steam or water. GE's research center invented a silicon carbide (SiC) photodiode that is significantly more sensitive to the longer wavelength components of the UV light generated by the flame. This longer wavelength light does penetrate the fog of oil quite well and therefore the SiC based sensor is significantly more sensitive to the presence of flame. A flame sensor utilizing the SiC photodiode is being produced by BHGE Reuter-Stokes, and has been successfully operated on a number of GE gas turbine installations.

2 SENSOR

Figure 1 is a block diagram of the SiC Flame Sensor. The sensor has a sapphire window that is transparent to UV light and can withstand the compressor discharge temperature and pressure. It has a lens inside that focuses the light on a silicon carbide photodiode in a hermetic package. The photodiode is wired to a MOSFET input amplifier. The amplifier has a high initial gain, which automatically shifts to a lower gain in order to accommodate a wide range of input light level without saturating. The sensor regulates the supply current in proportion to the amount of UV light present. Both power and signal are transmitted on the same two wires. The sensor can be powered from a dc voltage between 12 and 30 volts. The whole transducer is sealed and filled with dry argon.

Figure 1

SiC FLAME TRACKER™ WIRING DIAGRAM



3 INSTALLATION

3.1 MECHANICAL


The maximum operating temperature for the flame sensor is 302° F (150° C). If the peak operating temperature at the location of the sensor exceeds this then cooling will be required. There are two methods available for cooling: air-cooling with ambient air, and air-cooling with pressurized air.

Air-cooling with ambient air can be used in installations where the enclosure is cooled with forced air. This would be typical of LM2500 and LM6000 aircraft engine applications. The air velocity at the sensor must be 5 ft./sec (1.5 m/sec), or greater, at a temperature of 50° F (10° C), or less, above outside ambient. Under these conditions the sensors will operate at outside ambient temperatures up to 140° F (60° C).

Air cooling with pressurized air requires the use of Air Cooling Can BHGE Reuter-Stokes Part Number RS-E2-0259 (GE Part Number 07482SOCNL44821P01). The Air-Cooling Can is installed as shown in the following drawing. The Air-Cooling Can requires 25 psi (170 kPa) minimum at 120° F (49° C) maximum. Under these conditions the sensors will operate at ambient temperatures up to 302° F (150° C)

Do not complete step 2 in the “FLAME SENSOR AND WATER COOLING JACKET INSTALLATION INSTRUCTIONS” on the next page. Leave the sensors installed hand tight until after the sensor checkout described in Section 3.3.

FLAME SENSOR AND COOLING JACKET INSTALLATION INSTRUCTIONS




1. Ensure that the cooling coil is not attached to the flame sensor during installation or removal of the sensor. The cooling coil can apply an unwanted torque and cause disassembly and malfunction of the flame sensor.
2. Apply a small amount of Never-Seez PN NG-165 to threads of sight tube prior to installation. Be sure the Never-Seez applied to the sight tube is minimal and only applied below the 2nd thread. If Never-Seez is applied to the face of the sight tube, upon heating, it can fog the window of the Flame Sensor.
3. Inspect the window and clean with Isopropanol soaked swab. If required install hand tight (3-4 Full turns) tighten with a wrench approximately 2.5 turns. Tighten further as required to align keys on cable connector with slots in sensor connector

3.2 ELECTRICAL

The sensors are connected to the turbine junction box with a connector cable as specified in Section 1.1. All wiring must be in grounded conduit or armored. The green wire must be connected to earth ground at the junction box. Do not connect the shields over the twisted pair signal leads to each other or to earth ground at any location. The inner shields should be individually jumpered through all junction boxes and connected to the proper ground terminal at the Controller. The polarity of the cable is: red wire is positive and black wire is negative. The polarity is shown in the drawings. Reverse polarity will not damage the sensor. Signal cable from the junction box to the Controller should be 18 gauge (1.02 mm) twisted shielded pair. The extension cable from the junction box to the Controller is the customer's responsibility.

FIGURE 2 - MAXIMUM RESISTANCE VS. OPERATING VOLTAGE



The Flame Tracker™ is connected to the controller as a typical two wire current transmitter. It can be operated from any well-filtered dc supply from 12 volts to 30 volts. The supply should be capable of supplying 100 milliamps. The power supply must be protected to prevent the supply voltage from exceeding 30 volts in normal use and more than 42 volts under transient conditions. The sensor is protected against reverse polarity. The maximum value for the sense resistor plus the wire resistance is dependent on the supply voltage. At 24 volts this value is 560 ohms. Resistance values for other voltages can be determined from the chart in Figure 2.

3.3 CONNECTOR PINOUT

The pinout for the power connector is as follows:

CONNECTOR LEGEND		
PIN	CIRCUIT DESIGNATION	WIRE COLOR for RS-E2-0279PXXX cable
A	-	Black
B	+	Red
C	Ground	Green
D	Not Used	
E	Not Used	

3.4 SENSOR CHECKOUT

Disconnect the sensors and unscrew them from the turbine. Plug the sensor cables back in to each of the sensors. Apply power to the sensors. Check the current values at the controller for each of the sensors. The sensors are sensitive to light, and may have some reading, depending on the ambient light level. Test each sensor by covering the port to see zero flame intensity signal, and with a flashlight to see a positive reading. With no light the reading should be 3.7 to 4.1 milliamps, while with most flashlights the reading should be above 8 milliamps. An LED flashlight may not work for this application. Variations in flashlight type, strength, or battery voltage may cause variations in signal output. The flashlight test is intended as a field test for general functionality only and is not a controlled or quantitative test. If a sensor is outside these rough check limits see Section 5.0.

Disconnect the sensor cables, and reinstall the sensors according to the instruction in Section 3.1. At this time step 2 of Section 3.1 should be completed and the sensor cables reconnected. Make sure that the sapphire window is clean; if it needs cleaning, do this according to the maintenance instructions in Section 4.0. Check that all sensors are reading between 3.7 to 4.1 milliamps.

3.5 CONTROLLER SETUP

The Flame Sensor provides a minimum output of 5 milliamps when exposed to the minimum flame intensity specified in GE specification number 362A1052. The set point for flame off should be set to 6.25%, which is equal to 5 milliamps. The set point for flame on should be 10% of full scale, which equals 5.6 milliamps. If the intensity levels are too low for these settings there may be other problems. Low intensity levels may be a sign of other problems. Refer to Section 5.0 - Troubleshooting.

4 MAINTENANCE

4.1 WARNING

Do not disconnect connector while circuit is energized (or live), unless area is known to be non-hazardous.

4.2 CAUTION

The operating temperature range of the Flame Sensor is -40°C to 150°C. Do not attempt to work on the Flame Sensor or the cable until they have cooled to a safe handling temperature.

The Flame Sensor output will deteriorate as the lens becomes dirty. It is recommended, when initially installed, that the signal level be recorded during normal operation. During subsequent running, the signal level should be compared with the initial values. If a significant reduction in the signal level is noticed, then it is recommended that the lens be cleaned at the next opportunity (with the turbine shut down and cold). Clean the lens with isopropyl alcohol or other residue free solvent compatible with Sapphire. In order to reduce the risk of galling, an anti-seize compound should be applied to the mounting thread prior to reinstallation of the sensor.

5 TROUBLESHOOTING

5.1 WARNING

Do not disconnect connector while circuit is energized (or live), unless area is known to be non-hazardous.

5.2 CAUTION

The operating temperature range of the Flame Sensor is **-40°C to 150°C**. **Do not** attempt to work on the Flame Sensor or the cable until they have cooled to a safe handling temperature.

PROBLEM	CAUSE	SOLUTION
No current flows	Reversed polarity	Change polarity
Low sensitivity during checkout or operation	Dirty lens Grounded cable	Clean lens (Section 4.0) Check cable for grounds
Low flame intensity signal during operation	Misalignment of the sensor mount	Check the squareness of all flanges and pipes of the sensor mount. Verify that the sensor has a clear view of the flame.
	Obstructions in the line of sight	Look for washers, or valves that may restrict the diameter of the sight tube.
	Condensation on the lens	Over cooling can cause moisture to condense on the lens and reduce the signal. Reduce the cooling until the condensation clears up and the signal returns to normal.